

*the*  
**BOATER'S GUIDE**  
**of Arizona:**  
**A Handbook of Boating**  
**Laws and Responsibilities**



**Arizona Game and Fish Department**  
**[www.azgfd.gov](http://www.azgfd.gov)**

Welcome to Arizona's beautiful waterways. We in Arizona are fortunate to have some of the most breathtaking, expansive lakes and rivers in the country for our recreational enjoyment.

The past few years have seen a steady increase in both the numbers and diverse types of watercraft on our state's waterways, making the responsibilities of boating enforcement and education increasingly important and complex.

We at the Arizona Game and Fish Department are committed to providing you with an enjoyable boating experience. We've produced this guide to provide all boaters and water enthusiasts with a positive experience while using one of Arizona's most valuable resources, our waterways. In addition to courtesy and defensive boating, this information is designed to aid you by highlighting Arizona's boating laws on our state's waterways. We also encourage you to take a complete course on boating safety, available from our certified instructors throughout the state. For information, call 623-236-7258 or visit our website at [www.azgfd.gov/boating](http://www.azgfd.gov/boating).

Have a wonderful boating season, and obey the laws. Remember, "it only takes one"—one time not wearing a PFD (life jacket), one drink that puts you over the limit, or one second of reckless operation.

**The Arizona Game and Fish Department's Vision:**  
To be the national conservation leader supporting the continuation of the North American Model of Wildlife Conservation and Arizona's most trusted, respected, and credible source for wildlife conservation products, services, and information.

**The Arizona Game and Fish Department's Mission:**  
To conserve Arizona's diverse wildlife resources and manage for safe, compatible outdoor recreation opportunities for current and future generations.

*the* \_\_\_\_\_  
**BOATER'S GUIDE**  
of  
**Arizona:**

**A Handbook of  
Boating Laws and  
Responsibilities**



**Arizona Game and Fish Department**  
**5000 W. Carefree Hwy.**  
**Phoenix, AZ 85086**  
**602-942-3000**

**Arizona Game and Fish Department Regional Offices**

**Flagstaff**

**3500 S. Lake Mary Rd.**  
**Flagstaff, AZ 86001**  
**928-774-5045**

**Kingman**

**5325 N. Stockton Hill Rd.**  
**Kingman, AZ 86409**  
**928-692-7700**

**Mesa**

**7200 E. University Ave.**  
**Mesa, AZ 85207**  
**480-981-9400**

**Pinetop**

**2878 E. White Mountain Blvd.**  
**Pinetop, AZ 85935**  
**928-367-4281**

**Tucson**

**555 N. Greasewood Rd.**  
**Tucson, AZ 85745**  
**520-628-5376**

**Yuma**

**9140 E. 28th St.**  
**Yuma, AZ 85365**  
**928-342-0091**

---

Published by Boat Ed®, a division of Kalkomey Enterprises, LLC, 224 West Campbell Road #512, Richardson, TX 75080, 214-351-0461. Printed in the U.S.A.

Copyright © 2003–2025 by Kalkomey Enterprises, LLC. All rights reserved. No part of this publication may be reproduced in any form or by any process without permission in writing from Kalkomey Enterprises, LLC. Effort has been made to make this publication as complete and accurate as possible. All references contained in this publication have been compiled from sources believed to be reliable, and to represent the best current opinion on the subject. Kalkomey Enterprises, LLC is not responsible or liable for any claims, liabilities, damages, or other adverse effects or consequences to any person or property caused or alleged to be caused directly or indirectly from the application or use of the information contained in this publication. P0225

 **kalkomey™**  
[www.kalkomey.com](http://www.kalkomey.com)

---

The Arizona Game and Fish Department prohibits discrimination on the basis of race, color, sex, national origin, age, or disability in its programs and activities. If anyone believes that they have been discriminated against in any of the AZGFD's programs or activities, including its employment practices, the individual may file a complaint alleging discrimination directly with the AZGFD Deputy Director, 5000 W. Carefree Highway, Phoenix, AZ 85086, 602-942-3000 or U.S. Fish & Wildlife Service, 5275 Leesburg Pike, Falls Church, VA 22041. If you require this document in an alternative format, please contact the AZGFD Deputy Director as listed above or TTY at 1-800-367-8939.

Cover photo courtesy of Arizona Game and Fish Department staff

# **BOAT ARIZONA**

3

## **A Course on Responsible Boating**

Boater education is a good idea for all Arizona boaters. Not only will you learn how to boat safely, but becoming certified also can save you money on your boat or PWC insurance. You have **two** ways to be certified.



### **1. Over the Internet...**

Learn what you need to know to be a safe boat or personal watercraft (PWC) operator online! The complete course with exciting visuals awaits you on the Internet. Interactive graphics help you learn and retain information on boating safely in Arizona. Successfully complete the online test, and you will receive your boater education certificate by mail.

**Start today at [www.azgfd.gov/boating](http://www.azgfd.gov/boating).**

---

### **2. In a classroom...**

Share the learning experience with other interested students and a qualified instructor. Classes are available through the Arizona Game and Fish Department, the U.S. Coast Guard Auxiliary, the U.S. Power Squadrons, or your local county sheriff's office. The Arizona Game and Fish Department can help you find a classroom course in your area. For more information:

**Call 623-236-7258  
or visit [www.azgfd.gov/boating](http://www.azgfd.gov/boating).**

---

# Table of Contents

## Boating Basics

### Before Going Out

Vessel Length Classes.....	6
Vessel Capacity .....	6
Fueling a Vessel .....	7
Fuel Selector Switch on a PWC ..	8
Preventing Theft .....	8
Filing a Float Plan .....	9
Pre-Departure Checklist .....	10
Trailer Your Vessel Safely ....	10

### On the Water

Encountering Other Vessels ....	12
Navigation Rules .....	13
Nighttime Navigation .....	14

### U.S. Aids to Navigation

System (ATON) .....	16
Weather Emergencies .....	20
Carbon Monoxide Poisoning ...	22
Other Boating Emergencies ....	24
Cold Water Immersion .....	25

### Specifically for PWC

Steering and Stopping a PWC ..	26
Engine Cut-Off Switch (ECOS) .....	26
Reboarding a Capsized PWC ...	27
PWC Courtesy .....	28
Environmental Considerations ..	28
Other PWC Considerations ....	29

## It's the Law!

### Before Going Out

Registering Your Vessel .....	30
Other Facts About Vessel Registration.....	32
Vessel Registration Fees .....	33
Hull Identification Number (HIN).....	34
Who May Operate a Vessel.....	35
Marine Events .....	35
Enforcement .....	36

### Required Equipment

Personal Flotation Devices (Life Jackets) .....	37
Navigation Lights .....	39
Fire Extinguishers .....	41
Ventilation Systems .....	43
Backfire Flame Arrestors .....	44
Mufflers and Noise Level Limits .....	45
Sound-Producing Devices .....	45
Visual Distress Signals (VDSs) ..	46

## On the Water

Unlawful and Dangerous Operation .....	48
Alcohol and Drugs .....	50
Obstructing Navigation. ....	50
Accidents and Casualties .....	51
Diver-Down Flags .....	52
Discharge of Oil and Other Hazardous Substances. ....	52
Discharge of Sewage and Waste .....	53
Discharge of Trash .....	53

“Pull the Plug” Protocols .....	59
---------------------------------	----

Vessel and Engine Restrictions .....	60
--------------------------------------	----

Arizona Boater’s Directory .....	62
----------------------------------	----

Arizona Required Equipment Checklist .....	64
--	----

## Specifically for PWC

Requirements Specific to PWC. .	54
Sharing Your PWC...Safely ....	55

## Surface Watersports

Towed Sports .....	56
Hand Signals for Skiers .....	57
Avoiding Propeller Strike Injuries .....	58

## Stay Current on New Boating Laws

- Call the Arizona Game and Fish Department at **602-942-3000**.
- Visit the Arizona Game and Fish Department website at **[www.azgfd.gov/boating](http://www.azgfd.gov/boating)**.



Information in this booklet does not replace what is specifically legal for boating in Arizona, which is found in the Arizona Revised Statutes, Arizona Game and Fish Commission Rules, and federal laws.


# Before Going Out

Before going out on the water, take steps to make the outing safe and enjoyable.


## Vessel Length Classes

- A vessel's length class determines the equipment necessary to comply with federal and state laws.
- Vessels are divided into length classes:
  - Less than 16 feet
  - 16 feet to less than 26 feet
  - 26 feet to less than 40 feet
  - 40 feet to less than 65 feet
- Length is measured from the tip of the bow in a straight line to the stern. This does not include outboard motors, brackets, rudders, bow attachments, or swim platforms and ladders that are not a molded part of the hull.

### Inboards




### Outboards



## Vessel Capacity

- Always check the capacity plate, which is usually found near the operator's position or on the vessel's transom. This plate indicates the maximum weight capacity and maximum number of people that the vessel can carry safely.



- Personal watercraft (PWC) and some other vessels are not required to have a capacity plate. Always follow the recommended capacity in the owner's manual and on the manufacturer's warning decal.
- On vessels with no capacity plate, a simple formula can provide a guide. Multiply length (in feet) by width (in feet) and divide the result by 15. This will give you the maximum number of people at

$$\frac{L' \times W'}{15}$$

an average weight of 150 pounds that the boat will accommodate safely under calm water conditions. This information can be found on the U.S. Coast Guard's (USCG) boating safety website at [www.uscgboating.org](http://www.uscgboating.org).

## Fueling a Vessel

Never fuel at night unless it is an emergency. If you must refuel after dark, use only electric lights. Try to refuel away from the water or on a commercial fueling ramp. ***In Arizona, it is illegal to spill petroleum products on the waterways or beaches while refueling a vessel.***

### ■ Before beginning to fuel:

- Dock the boat securely, and ask all passengers to exit.
- Do not allow anyone to smoke or strike a match.
- Check all fuel lines, connections, and fuel vents.
- Turn off anything that might cause a spark—engines, fans, or electrical equipment.
- Shut off all fuel valves, and extinguish all open flames, such as galley stoves and pilot lights.
- Close all windows, ports, doors, and other openings to prevent fumes from entering the boat.
- Remove portable fuel tanks, and fill them on the dock.

### ■ While filling the fuel tank:

- Keep the nozzle of the fuel-pump hose in contact with the tank opening to prevent producing a static spark.
- Avoid spilling fuel into the boat's bilge or the water.
- Never fill a tank to the brim—leave room to expand.
- Wipe up any spilled fuel.

### **The most important safe fueling practice...**

If your vessel is equipped with a power ventilation system, turn it on for at least four minutes both after fueling and before starting your engine to remove gas vapors in the bilge.

### ■ After fueling:

- Open all windows, ports, doors, and other openings.
- Before starting the engine, sniff the bilge and engine compartment for fuel vapors.


## Additional Safety Procedures for PWC

- Do not tip the PWC in order to fill it all the way up. If the tank is overfilled, the fuel may expand and spill into the water.
- After fueling, open the door of the engine compartment, and sniff to check for any evidence of gas fumes. Do this before starting the engine. If you do smell gas fumes, determine the source, and make repairs immediately.

## Fuel Selector Switch on a PWC

This switch can help you avoid becoming stranded without fuel.

- Use the “Off” position when the PWC’s engine is turned off.
- Use the “On” position while you are underway.
- Use the “Reserve” position if you run out of fuel while underway. This will allow you to return to shore. Don’t forget to switch back to “On” after refueling.



## Preventing Theft

Defend against theft of your vessel and equipment.

- Store your vessel so that it is not easily accessed.
  - Store your vessel and trailer in a locked garage or storage area.
  - Park another vehicle in front of the trailer, or lock the trailer to a fixed object in a well-lit area.
  - Secure the vessel and trailer to a fixed object with a good-quality chain and lock. If moored, secure the vessel to the dock with a steel cable and lock.
  - Remove a trailer wheel if parked for an extended time.
  - Purchase a quality trailer hitch lock, and use it.

- Chain and lock the motor and fuel tanks to the vessel.
- Mark or engrave all equipment with an identifier, such as your driver's license number.
- Photograph or videotape the interior and exterior of your vessel, showing all installed equipment and additional gear and equipment. Make a complete inventory of your equipment, vessel, and trailer.
- Remove expensive electronics or other valuables if the vessel is left unattended.
- Cover your vessel, and always remove the keys.
- Title and/or register your vessel.
- Remove the Certificate of Number (registration card) when the vessel is not being operated.

## Filing a Float Plan

Before going out on a vessel, it is always a good idea to leave a float plan with a relative or friend, or at least with a local marina.

- A float plan should:
  - Describe the vessel, including its registration number, length, make, horsepower, and engine type.
  - State where you are going, the detailed route, your planned departure time, and your expected return time.
  - Give the name, address, and telephone number of each person on board and an emergency contact.
  - Include the description and license plate of the tow vehicle and trailer, and tell where they will be located.
- Notify the person who has your float plan when you return or if you decide to extend your time on the water.

**boat-ed.com**  
Get Your Boat Certified

**FLOAT PLAN**

Complete this form before going out on your boat, and leave it with a reliable person who will notify the Coast Guard and local authorities if you do not return on schedule. If you are delayed and it is not an emergency, please let your person who has your plan to avoid an unnecessary search.

1. Name of person filing this plan: \_\_\_\_\_

2. Description of boat: \_\_\_\_\_  
 Make \_\_\_\_\_ Model \_\_\_\_\_  
 Year \_\_\_\_\_ Length \_\_\_\_\_ Motor \_\_\_\_\_  
 Make \_\_\_\_\_ Model \_\_\_\_\_

3. Name of person on board: \_\_\_\_\_  
 Name \_\_\_\_\_ Age \_\_\_\_\_ Address \_\_\_\_\_  
 Telephone # \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

4. Description of engine: Type \_\_\_\_\_ Horsepower \_\_\_\_\_ # of engines \_\_\_\_\_ Fuel capacity \_\_\_\_\_

5. General registration: State \_\_\_\_\_ Title \_\_\_\_\_ Registration \_\_\_\_\_ License \_\_\_\_\_  
 License Plate # \_\_\_\_\_  
 Trailer \_\_\_\_\_ License Plate # \_\_\_\_\_  
 Trailer \_\_\_\_\_ License Plate # \_\_\_\_\_

6. Towing vehicle: Make \_\_\_\_\_ Model \_\_\_\_\_ Year \_\_\_\_\_ License Plate # \_\_\_\_\_  
 Trailer \_\_\_\_\_ License Plate # \_\_\_\_\_

7. Other pertinent information: Date \_\_\_\_\_ Time \_\_\_\_\_ Day \_\_\_\_\_ Night \_\_\_\_\_ Weather \_\_\_\_\_

8. Description of activities: Fishing \_\_\_\_\_ Hunting \_\_\_\_\_ Water skiing \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

9. Fuel information: Type \_\_\_\_\_ Amount \_\_\_\_\_ Location \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

10. Contact information: Name \_\_\_\_\_ Address \_\_\_\_\_  
 Phone \_\_\_\_\_ Email \_\_\_\_\_

## Pre-Departure Checklist

You can help ensure a good time while operating your vessel by performing this pre-departure check.

- ✓ Check the weather forecast for the area and time frame during which you will be boating. High winds create hazardous conditions for boaters.
- ✓ Make sure that the steering and throttle controls operate properly and all lights are working properly.
- ✓ Check for any fuel leaks from the tank, fuel lines, and carburetor.
- ✓ Check the engine compartment for oil leaks.
- ✓ Check hose connections for leaks or cracks, and make sure hose clamps are tight.
- ✓ Drain all water from the engine compartment, and be sure the bilge plug is replaced and secure.
- ✓ Check to be sure you have a fully charged engine battery and fire extinguishers.
- ✓ If so equipped, make sure the engine cut-off switch (ECOS) and wrist lanyard are in good order.
- ✓ Make sure you have the required number of life jackets (personal flotation devices or PFDs), and check that they are in good condition.
- ✓ Leave a float plan with a reliable friend or relative.

## Trailing Your Vessel Safely

### ■ Before leaving home:

- Secure all gear in the vessel, and arrange it so that the weight is evenly distributed in the vessel.
- Properly secure the vessel with several tie-down straps and/or safety lines to prevent it from shifting.
- Tilt and secure the engine to increase clearance.
- Crisscross the safety chains when attaching them to the towing vehicle.
- Make sure the trailer brakes and lights are working.

**■ On the road:**

- Think farther ahead on the road than usual. Anticipate changes in traffic flow in advance, make wider turns at corners and curves, allow extra time and distance for stopping and for passing other vehicles, and remember the length added by your trailer.
- Be aware that there may be lower speed limits for vehicles with trailers.
- After 5 to 10 miles of travel at highway speed, stop for a walk-around inspection of the vehicle and trailer. Check tires, lights, coupler, etc., and feel the trailer hubs. Excessively hot hubs may indicate a problem. On extended trips, make periodic stops to do a walk-around inspection.

**■ Launching your vessel from a trailer:**

- Prepare your vessel well away from the boat ramp.
- Back the vessel into the water until the lower unit of the engine can be submerged while on the trailer.
- Once the engine is warmed up, back the trailer further until the vessel floats. Then back slowly off the trailer.

**■ Retrieving your vessel:**

- Back the trailer into the water so that approximately two-thirds of the rollers or bunks are submerged.
- Move the vessel onto the trailer far enough to attach the winch line to the bow eye of the vessel. Finish pulling it onto the trailer by cranking the winch.
- Tow the vessel off the ramp out of the way of others.
- While at the ramp area, remove all weeds from the vessel, remove the drain plug, and drain live wells.

## On the Water

Safe navigation on Arizona waterways is everyone's responsibility. Every operator is responsible for knowing and following the relevant navigation rules. You are legally obligated to know the rules and to apply them to avoid collisions.

### Encountering Other Vessels

There are some rules that every operator should follow when encountering other vessels. It is the responsibility of both operators to take the action needed to avoid a collision. The next page shows what to do when encountering another vessel.

**To prevent collisions, every operator should follow the three basic rules of navigation.**

- Practice good seamanship.
- Keep a sharp lookout.
- Maintain a safe speed and distance.







### Encountering Vessels With Limited Maneuverability

- When operating a power-driven vessel, you must give way to:
  - Any vessel not under command, such as an anchored or disabled vessel
  - Any vessel restricted in its ability to maneuver, such as a vessel towing another or laying cable, or one constrained by its draft, such as a large ship in a channel
  - A vessel engaged in commercial fishing
  - A sailboat under sail unless it is overtaking
- When operating a vessel under sail, you must give way to:
  - Any vessel not under command
  - Any vessel restricted in its ability to maneuver
  - A vessel engaged in commercial fishing

## Navigation Rules

There are two terms that help explain these rules.


- **Stand-on vessel:** The vessel that should maintain its course and speed
- **Give-way vessel:** The vessel that must take early and substantial action to avoid collision by stopping, slowing down, or changing course

Power vs. Power		Power vs. Sail
	<p><b>Meeting Head-On</b>  <b>Power vs. Power:</b> Neither vessel is the stand-on vessel. Both vessels should keep to the starboard (right).   <b>Power vs. Sail:</b> The powerboat is the give-way vessel. The sailboat is the stand-on vessel.</p>	
	<p><b>Crossing Situations</b>  <b>Power vs. Power:</b> The vessel on the operator's port (left) side is the give-way vessel. The vessel on the operator's starboard (right) side is the stand-on vessel.   <b>Power vs. Sail:</b> The powerboat is the give-way vessel. The sailboat is the stand-on vessel.</p>	
	<p><b>Overtaking</b>  <b>Power vs. Power:</b> The vessel that is overtaking another vessel is the give-way vessel. The vessel being overtaken is the stand-on vessel.   <b>Power vs. Sail:</b> The vessel that is overtaking another vessel is the give-way vessel. The vessel being overtaken is the stand-on vessel.</p>	


## Nighttime Navigation

Be on the lookout for the lights of other vessels when boating at night. Several types of lights serve as navigational aids at night. There are four common navigation lights.


- **Sidelights:** These red and green lights are called sidelights (also called combination lights) because they are visible to another vessel approaching from the side or head-on. The red light indicates a vessel's port (left) side; the green indicates a vessel's starboard (right) side.
- **Sternlight:** This white light is seen from behind or nearly behind the vessel.
- **Masthead Light:** This white light shines forward and to both sides and is required on all power-driven vessels. A masthead light must be displayed by all vessels when under engine power. The absence of this light indicates a sailboat under sail.
- **All-Round White Light:** On power-driven vessels less than 39.4 feet in length, this light may be used to combine a masthead light and sternlight into a single white light that can be seen by other vessels from any direction. This light serves as an anchor light when sidelights are extinguished.




## Encountering Vessels at Night



When you see only a white light, you are overtaking another vessel. It is the stand-on vessel whether it is underway or anchored. You may go around it on either side.





When you see a green and a white light, you are the stand-on vessel. However, remain alert in case the other vessel operator does not see you or does not know the navigation rules.



When you see a red and a white light, you must give way to the other vessel. Slow down and allow the vessel to pass, or you may turn to the right and pass behind the other vessel.

## Encountering a Sailboat at Night

When you see **only a red light** or **only a green light**, you may be approaching a sailboat under sail, and you must give way. The sailboat under sail is always the stand-on vessel.



## U.S. Aids to Navigation System (ATON)


Buoys and markers are the “traffic signals” that guide vessel operators safely along some waterways. They also identify dangerous or controlled areas and give directions and information. As a recreational boat or PWC operator, you will need to know the lateral navigation markers and non-lateral markers of the U.S. Aids to Navigation System (ATON).

### Lateral Markers

These navigation aids mark the edges of safe water areas; for example, directing travel within a channel. The markers use a combination of colors and numbers, which may appear on either buoys or permanently placed markers.

#### **Red colors, red lights, and even numbers**


indicate the right side of the channel as a boater enters from the open sea or heads upstream.



#### **Green colors, green lights,**

**and odd numbers** indicate the left side of the channel as a boater enters from the open sea or heads upstream.

**Red and green colors and/or lights** indicate the preferred (primary) channel. If green is on top, the preferred channel is to the right as a boater enters from the open sea or heads upstream; if red is on top, the preferred channel is to the left.



**Nuns** are red cone-shaped buoys marked with even numbers.



**Cans** are green cylindrical-shaped buoys marked with odd numbers.



**Lighted Buoys** use the lateral marker colors and numbers discussed above; in addition, they have a matching colored light.



**Daymarks** are permanently placed signs attached to structures, such as posts, in the water. Common daymarks are red triangles (equivalent to nuns) and green squares (equivalent to cans). They may be lit also.



## Red Right Returning

is a reminder of the correct course when returning from open waters or heading upstream.

## Non-Lateral Markers

Non-lateral markers are navigational aids that give information and regulations. The most common are regulatory markers. These markers are white with orange stripes on the top and bottom and have a geometric shape between the stripes. The shapes indicate the purpose of the markers as shown below.



### Information

Squares indicate where to find food, supplies, repairs, etc., and give directions and other information.



### Controlled

Circles indicate a controlled area, such as speed limit, no fishing or anchoring, ski only or no skiing, or “slow, no wake.”



### Exclusion

Crossed diamonds indicate areas off-limits to all vessels, such as swimming areas, dams, and spillways.



### Danger

Diamonds warn of dangers, such as rocks, shoals, construction, dams, or stumps. Always proceed with caution.

## Other Non-Lateral Markers

**Safe Water Markers** are white with red vertical stripes and mark mid-channels or fairways. They may be passed on either side.



**Inland Waters Obstruction Markers** are white with black vertical stripes and indicate an obstruction to navigation. You should not pass between these buoys and the nearest shore.

## Mooring Buoy

Mooring buoys are white with a blue horizontal band and are found in marinas and other areas where vessels are allowed to anchor.

- Willfully damaging, removing, interfering with, or tying up to a navigation buoy not intended for mooring is illegal.
- Mooring, anchoring, or fastening to shore for more than 14 consecutive days any vessel on public waters is illegal unless:
  - The vessel is moved 25 nautical miles or more from its previous location **or...**
  - The vessel is in a special anchorage area, is authorized for private dock or moorage, or is authorized by the government agency or private interest with jurisdiction over the waters.



## Weather Emergencies

Weather can change very rapidly and create unexpected situations for boat operators, and weather-related accidents in Arizona are on the rise. Even meteorologists have trouble predicting rapid weather changes. You should always monitor weather developments. One way is to tune a VHF radio to the frequencies listed on the next page. Then seek a protected area before the weather becomes a threat.

### What to Do if Caught in Severe Weather

#### ■ **Prepare the boat to handle severe weather.**

- Slow down, but keep enough power to maintain headway and steering.
- Close all hatches, windows, and doors to reduce the chance of swamping.
- Stow any unnecessary gear.
- Turn on your boat's navigation lights. If there is fog, sound your foghorn.
- Keep bilges free of water. Be prepared to remove water by bailing.
- If there is lightning, disconnect all electrical equipment. Stay as clear of metal objects as possible.

#### ■ **Prepare your passengers for severe weather.**

- Have everyone put on a USCG–approved life jacket. If passengers are already wearing their life jackets, make sure they are secured properly.
- Have your passengers sit on the vessel floor close to the centerline for their safety and to make the boat more stable.

#### ■ **Decide whether to go to shore or ride out the storm.**

- If possible, head for the nearest shore that is safe to approach. If already caught in a storm, it may be best to ride it out in open water rather than try to approach the shore in heavy wind and waves.
- Head the bow into the waves at a 45-degree angle. PWC should head directly into the waves.

- If the engine stops, drop a “sea anchor” on a line off the bow to keep the bow headed into the wind and reduce drifting while you ride out the storm. In an emergency, a bucket will work as a sea anchor.
- If the sea anchor is not sufficient, anchor using your conventional anchor to prevent your boat from drifting into dangerous areas.

### VHF Frequencies Broadcasting NOAA Weather Reports

<b>162.400 MHz</b>	<b>162.450 MHz</b>	<b>162.500 MHz</b>	<b>162.550 MHz</b>
<b>162.425 MHz</b>	<b>162.475 MHz</b>	<b>162.525 MHz</b>	

These are the most commonly used VHF channels on United States waters.

**Channel 6** Intership safety communications.

**Channel 9** Communications between vessels (commercial and recreational), and ship to coast (calling channel in designated USCG districts).

**Channel 13** Navigational use by commercial, military, and recreational vessels at bridges, locks, and harbors.

**Channel 16** Distress and safety calls to USCG and others, and to initiate calls to other vessels; often called the “hailing” channel. (Some regions use other channels as the hailing channel.) When hailing, contact the other vessel, quickly agree to another channel, and then switch to that channel to continue conversation.

**Channel 22** Communications between the USCG and the maritime public, both recreational and commercial. Severe weather warnings, hazards to navigation, and other safety warnings are broadcast on this channel.

**Channels 24–28** Public telephone calls (to marine operator).

**Channels 68, 69, and 71** Recreational vessel radio channels and ship to coast.

**Channel 70** Digital selective calling “alert channel.”

## Carbon Monoxide Poisoning

Carbon monoxide is a colorless, odorless, tasteless gas that is very toxic even in small quantities. It is produced when a carbon-based fuel, such as gasoline or diesel, is burned. Cooking ranges, heaters, and charcoal grills produce carbon monoxide also.

### Carbon Monoxide Kills

- Carbon monoxide disperses freely through the air and will travel readily throughout a boat.
  - Carbon monoxide discharged as engine, generator, or appliance exhaust may re-enter your boat through any opening.
  - A marine-type carbon monoxide detector will sound an alarm when the gases reach an unacceptable level.
- The best prevention for carbon monoxide poisoning is knowing that carbon monoxide exists.
  - By keeping a steady flow of fresh air moving through your boat, you will eliminate much, if not all, of the hazard. The danger comes when there are pockets of stagnant air loaded with carbon monoxide that are not flushed from your boat.
  - When operating any type of watercraft, be careful running downwind because exhaust gases may blow back on board.
- Everyone should know the symptoms and treatment of carbon monoxide poisoning.



## Symptoms of Carbon Monoxide Poisoning

One or more of the following symptoms may signal the adverse effects of carbon monoxide accumulations:

- Throbbing temples
- Inattentiveness or lack of concentration
- Inability to think coherently
- Ringing in the ears
- Tightness across the chest
- Headache, drowsiness, nausea, dizziness, fatigue, vomiting, collapse, and convulsions

For additional information, read ***Boaters: Protect Yourself from this Silent Killer! Carbon Monoxide***, a brochure produced by the Arizona Game and Fish Department (AZGFD) that is available by contacting your nearest AZGFD office.

## Treatment of Carbon Monoxide Poisoning

Evacuate, ventilate, investigate, and seek medical help.

**Teak surfing, platform dragging, wake surfing, and water-skiing within 12 feet of a moving watercraft can be fatal.**



**Swim Platform**

**Exhaust Port**

- Stay away from the exhaust ports—carbon monoxide builds up in areas near exhaust vents.
- DO NOT swim in areas where carbon monoxide may accumulate, such as the cavity between the swim platform and the stern of the boat.

## Other Boating Emergencies

A safe boater knows how to prevent and respond to other boating emergencies.

### Falling Overboard

#### ■ To prevent persons from falling overboard:

- Don't sit on the gunwale, bow, seat backs, motor cover, or any other area not designed for seating.
- Don't sit on pedestal seats when underway at greater than idle speed.
- Don't stand up in or lean out from the boat.
- Don't move about the boat when underway.



#### ■ If someone on your boat falls overboard:

- Reduce speed, and toss the victim a throwable device.
- Have other passengers watch the victim.
- Turn your boat around and slowly pull alongside the victim, approaching the victim from downwind or into the current, whichever is stronger.
- Turn off the engine. Pull the victim on board over the stern, keeping the weight in the boat balanced.

### Capsizing or Swamping

#### ■ To reduce the risk of capsizing or swamping:

- Don't overload your boat. Balance the load.
- Slow your boat appropriately when turning.
- Secure the anchor line to the bow, never to the stern.
- Don't boat in rough water or in bad weather.


#### ■ If you capsize or swamp your boat, or if you have fallen overboard and can't get back in:

- Stay with the boat.
- Try to reboard or climb onto it in order to get as much of your body out of the cold water as possible.

- **If the boat sinks or floats away,** don't panic.
  - If wearing a life jacket, remain calm and await help.
  - If you aren't wearing a life jacket, look around for one or for other buoyant items to use as a flotation device.
  - In cold water, float rather than tread.

## Cold Water Immersion

- **If you are boating in cold water:**
  - Dress in several layers of clothing under your life jacket, or wear a wetsuit or drysuit.
  - Learn to recognize the symptoms of hypothermia. Symptoms begin with shivering and bluish lips and nails, and progress to a coma and, ultimately, death.
- **To reduce the effects of hypothermia:**
  - Put on a life jacket if not wearing one. It helps you to float without excessive movement and insulates your body.
  - Get as much of your body out of the water as possible.
  - Don't take your clothes off unless necessary—clothes can help you float and provide insulation.
  - Don't thrash or move about. Excess motion consumes energy and increases loss of body heat.
  - Draw your knees to your chest and your arms to your sides, protecting the major areas of heat loss.
  - If others are in the water with you, huddle together with your arms around their shoulders.



## Specifically for PWC

Although a PWC is considered an inboard vessel and comes under the same rules and requirements of any other vessel, there are specific considerations for the PWC operator.

### Steering and Stopping a PWC

#### steering control



#### steering nozzle

- PWC are propelled by drawing water into a pump and then forcing it out under pressure through a steering nozzle at the back of the unit. This “jet” of pressurized water is directed by the steering control—when the steering control is turned, the steering nozzle turns in the same direction. For example, if the steering control is turned right, the nozzle turns right and the jet of water pushes the back of the vessel to the left, which causes the PWC to turn right.

#### **Remember—no power means no steering control...**


Most PWC and other jet-drive vessels must have power in order to maintain control. If you allow the engine on a PWC or other jet-propelled vessel to return to idle or shut off during operation, you may lose all steering control. Many PWC will continue in the direction they were headed before the engine was shut off, no matter which way the steering control is turned. New PWC allow for off-throttle steering.

- **Most PWC do not have brakes.** Always allow plenty of room for stopping. Just because you release the throttle or shut off the engine does not mean you will stop immediately. Even PWC that have a braking system do not stop immediately.

### Engine Cut-Off Switch (ECOS)

- Most PWC and powerboats come equipped by the manufacturer with an important device called an emergency engine cut-off switch (ECOS). If properly worn, this is a safety device that is designed to shut off the engine if the operator is thrown from the proper operating position. The USCG requires that operators of vessels equipped with an ECOS use the device at all times.

- A lanyard is attached to the ECOS and to the operator's wrist or the operator's life jacket. This switch shuts off the engine if the operator falls off the PWC or out of the powerboat. If your vessel does not come equipped with an ECOS, you should have one installed.
- In many states, it is illegal to ride your PWC without attaching the lanyard properly between the switch and yourself.



### Remember...

Operators of recreational vessels less than 26 feet in length are required to use the ECOS if the vessel is equipped with such a device. Operators must use the ECOS whenever the vessel is operating on plane or above displacement speed.

Be sure to check with the state boating agency where you are boating to determine how this new USCG rule applies locally. For more information on this requirement, visit [www.uscgboating.org/recreational-boaters/engine-cut-off-switch-faq.php](http://www.uscgboating.org/recreational-boaters/engine-cut-off-switch-faq.php).

## Reboarding a Capsized PWC

After a fall, the PWC could be overturned completely. You should be familiar with the proper procedure to right the PWC and to reboard from the rear of the craft.

- Most manufacturers have placed a decal at the rear or bottom of the craft that indicates the direction to roll your PWC to return it to an upright position. If no decal exists, check your owner's manual, or ask the dealer. If you roll it over the wrong way, you could damage your PWC.
- Practice reboarding with someone else around to make sure you can handle it alone. Don't ride your PWC if you are very tired because reboarding would be difficult. Also, avoid riding where there are strong currents or winds, which could hamper your reboarding efforts.



## PWC Courtesy

- Avoid congregating with other PWC operators near shore, which increases annoying noise levels.
- Avoid making excessive noise near residential and camping areas, particularly early in the morning. Excessive use in one area can be an irritant to people who are there to enjoy a quiet and relaxing time.
- Avoid maneuvers that cause the engine exhaust to lift out of the water because that increases noise levels.
- Do not modify your engine exhaust system if it increases the noise. Improperly modified exhausts will not make your PWC faster and may raise the noise to an illegal level.

## Environmental Considerations

When operating your PWC, consider the effect you may have on the environment.

- Make sure that the water you operate in is at least 30 inches deep. Riding in shallow water can cause bottom sediments or aquatic vegetation to be sucked into the pump, damaging your PWC and the environment.
- Avoid causing erosion by operating at slow speed and by not creating a wake when operating near shore or in narrow streams or rivers.
- Do not dock or beach your PWC in reeds and grasses. This could damage fragile environments.
- Take extra care when fueling your PWC in or near the water. Oil and gasoline spills are very detrimental to the aquatic environment. Fuel on land if possible.
- Never use your PWC to disturb, chase, or harass wildlife.



## Other PWC Considerations

- Remember that everyone on board a PWC must wear a life jacket. A high-impact life jacket is recommended.
- Keep hands, feet, loose clothing, and hair away from the pump intake area. Before cleaning debris away from the pump intake, be sure to shut off the engine.
- Keep everyone clear of the steering nozzle unless the PWC is shut off. The water jet can cause severe injuries.
- Frequently inspect your PWC's electrical systems (e.g., starter and engine gauge connections) to ensure there is no potential for electrical spark. Gas fumes could collect in the engine compartment, and an explosion could occur. After fueling, sniff the engine compartment for any evidence of gas fumes.
- Never exceed the manufacturer's recommended capacity for your PWC.
- Know your limits, and ride according to your abilities.



### Become a Certified Boater

Take a boater education class from the AZGFD to:

- ✓ Improve your family's safety on the water.
- ✓ Increase your boating knowledge and enjoyment.
- ✓ Be qualified for vessel insurance discounts.

**Visit [www.azgfd.gov/boating](http://www.azgfd.gov/boating) or call 623-236-7258 to find a class near you.**

## Before Going Out

All operators are required to obey laws that regulate the registration and operation of their vessels.

### Registering Your Vessel

- You must have an Arizona Certificate of Number (registration number) and registration decals to operate, moor, or anchor your vessel legally on the waterways of Arizona. The only exceptions are:
  - Non-motorized vessels
  - Vessels used solely as lifeboats
  - Vessels documented with the U.S. Coast Guard (USCG)
  - Vessels with valid registration in another state or country that are on the waters of Arizona for 60 or fewer consecutive days

- *The Certificate of Number (registration card) must be on board and available for inspection by a law enforcement officer whenever the vessel is operated.*

ARIZONA WATERCRAFT CERTIFICATE OF NUMBER					
Registration No. AZ 6266BS			Expires on 12/31/2025		
SAMPLE REGISTRATION 5000 W CAREFREE HIGHWAY PHOENIX AZ 85086					
Name SAMPLE BOAT		ISSUE DATE 01/08/2025			
HULL ID # SAMP1234A212		MODEL YEAR 2012		LENGTH 10 FT 0 IN	
USE RP	HULL TYPE PW	HULL MATERIAL FI	PROP IJ	FUEL GA	STATE OF USE AZ
(Owner Signature) _____					

- The registration number and registration decals must be displayed as follows.
  - Number must be painted, applied as a decal, or otherwise affixed to both sides of the bow.
  - Number must read from left to right on both sides of the bow.
  - Number must be in at least three-inch-high **BLOCK** letters.
  - Number's color must contrast sharply with its background.
  - Letters must be separated from the numbers by a space or hyphen: **AZ 6266 BS** or **AZ-6266-BS**.
  - No other numbers may be displayed on either side of the bow.
  - Decals must be affixed to both sides of the vessel within three inches in front of the **AZ** of the registration number.

## Registration Decal



**Spaces or hyphens  
should appear here.**

- If your vessel requires registration, it is illegal to operate it or allow others to operate your vessel unless it is registered and numbered as described above.

### Where to Register

Applications for new boats, transfers of ownership, and duplicate registrations can be processed through the mail or at any Arizona Game and Fish Department (AZGFD) office (listed toward the end of this handbook). Please call **602-942-3000** before sending your application through the mail to ensure that the proper evidence and fees are submitted.

### How to Renew

- Online at [watercraft.azgfd.com](http://watercraft.azgfd.com):
  1. Select Start.
  2. Know Your AZ Boat Number.
- In person at any AZGFD office or third-party vendor
- By mail

For the latest information on vessel fees, registration questions, and third-party vendors, contact any AZGFD office, call **602-942-3000**, or visit [www.azgfd.com/boating/register-and-renew-your-license/](http://www.azgfd.com/boating/register-and-renew-your-license/).

## Other Facts About Vessel Registration

Arizona is a non-title state.

- Vessel registration is staggered, similar to motor vehicle registration. The color and date on the registration decals indicate when the registration expires.
- The application for transfer of ownership must be made within 15 days of purchase.
- If you change your address, you must notify the AZGFD within 15 days either in writing or online at **[www.azgfd.gov/boating](http://www.azgfd.gov/boating)**.
- If you purchase a numbered vessel or if your watercraft is sold, stolen, lost, destroyed, or abandoned, you must report it to the AZGFD within 15 days.
- If you lose or destroy your Certificate of Number or decal, you may apply in person, by mail, or through a third-party vendor for a duplicate.
- Vessels registered in another state or country may operate on Arizona waters for 60 or fewer consecutive days before Arizona registration and numbering are required.
- Under federal and state laws, you must register your watercraft in the state of principal use. If your watercraft is used for over 60 consecutive days in Arizona waters, then you must register your watercraft in Arizona.
- Larger recreational vessels owned by U.S. citizens may (at the option of the owner) be documented by the USCG. Call the USCG at **1-800-799-8362** for more information.

## Vessel Registration Fees

An annual registration fee is required for each motorized vessel, including those with electric motors. The fees are as follows.

<b>Resident</b>	
Length of Watercraft	Registration Fee
0 to 12 ft.	\$20.00
12 ft. 1 in. to 16 ft.	\$22.00
16 ft. 1 in. to 20 ft.	\$30.00
20 ft. 1 in. to 26 ft.	\$35.00
26 ft. 1 in. to 39 ft.	\$39.00
39 ft. 1 in. to 64 ft.	\$44.00
64 ft. 1 in. and over	\$66.00

<b>Non-Resident</b>			
Length of Watercraft	Registration Fee	*NBSIF Fee	Total
0 to 12 ft.	\$20.00	\$80.00	\$100.00
12 ft. 1 in. to 16 ft.	\$22.00	\$88.00	\$110.00
16 ft. 1 in. to 20 ft.	\$30.00	\$192.00	\$222.00
20 ft. 1 in. to 26 ft.	\$35.00	\$224.00	\$259.00
26 ft. 1 in. to 39 ft.	\$39.00	\$253.00	\$292.00
39 ft. 1 in. to 64 ft.	\$44.00	\$286.00	\$330.00
64 ft. 1 in. and over	\$66.00	\$429.00	\$495.00

Duplicate Certificate of Number      \$8.00


Late Registration Penalty      \$5.00

\*In addition to the watercraft registration fees, non-residents must pay the Non-Resident Boating Infrastructure Fee (NBSIF). The NBSIF is used to pay for boating safety, law enforcement, and emergency response and to fund improvements to public launch ramps, public piers, restrooms, parking areas, picnic areas, and other similar facilities.

## Hull Identification Number (HIN)

The Hull Identification Number (HIN) is a unique 12-digit number assigned by the manufacturer to vessels built after 1972.

- These numbers distinguish one vessel from another. They are engraved in the fiberglass or on a metal plate attached to the transom. You should write down your HIN and put it in a place separate from your vessel in case warranty problems arise or your vessel is stolen.



- Owners of vessels that do not have the HIN must contact the AZGFD prior to registration.
- It is illegal to remove or alter the HIN.

### Proof of Ownership Required to Register

To register a vessel, you must provide as evidence of ownership a complete bill of sale, a court decree, or an original Certificate of Origin. If the vessel was registered in another state, you must provide the original title or registration (if a non-title state).

- If a bill of sale is presented, it must include:
  - Buyer's name and seller's name and signature
  - Manufacturer's name
  - HIN (vessels manufactured after 1972)
  - Previous registration number (if applicable)
  - Purchase price
  - Sales tax paid if purchased from a dealer or at an auction.

An Arizona business purchasing a vessel for rental or resale must complete a tax exemption form. Call the AZGFD (602-942-3000) for questions regarding sales or use tax.
- If registered in another state, the signed original title or registration must be submitted.

## Who May Operate a Vessel

Arizona law states that it is illegal for a person under the age of 12 to operate a vessel with a motor greater than 8 horsepower (which includes PWC) unless:

- An emergency exists **or...**
- The child's parent or legal guardian is on board **or...**
- Another person at least 18 years of age is on board.

### Arizona's Top 10 Boating Violations

1. No fire extinguisher
2. No throwable flotation device
3. Bow or transom riding
4. Excess speed in a no wake zone
5. Insufficient life jackets (personal flotation devices or PFDs)
6. Failure to remove plug (Aquatic Invasive Species)
7. Child not wearing a life jacket
8. Operating while impaired
9. Expired registration
10. Navigation rule violation

## Marine Events

- To hold a marine event on federally controlled waters, you must obtain a permit from the USCG.
- When the marine event is held on state waters, a permit may be required by the controlling organization for that body of water. The event sponsor is responsible for ensuring the public's welfare.
- Events held on the Colorado River require a permit from the USCG Sector San Diego.
- Vessel operators competing in marine events may test the vessels prior to the event only if the operators have first obtained a permit from the AZGFD.

## Enforcement

The boating laws of Arizona are enforced by AZGFD officers, county deputy sheriffs, municipal officers, park rangers, and any other state-commissioned law enforcement officers. The officers have the authority to stop and board vessels to check for compliance with state laws. The USCG has federal enforcement authority on all federally controlled waters.

- When hailed by an officer, the operator of a vessel must immediately stop and maneuver in such a way as to permit the officer to come alongside.
- Failure to obey an order or to comply with an officer will result in an enforcement action up to and including arrest.
- Officers may issue citations and may order an operator of a vessel back to shore to correct a violation. Some Arizona waterways, such as the Colorado River, are shared with other states. On these shared waterways, laws from these other states apply—as well as federal regulations. To ensure that you are obeying all applicable laws, make sure you are knowledgeable about all the laws and regulations for the specific waterway you are using.
- Officers may establish sobriety checkpoints on the waterways to ensure public safety.



Courtesy of Arizona Game and Fish Department staff

## Required Equipment

When preparing to go out on a vessel, the operator should check that the legally required equipment is on board.

### Personal Flotation Devices (Life Jackets)


- All vessels, including paddleboards and kayaks, must have at least one USCG–approved wearable life jacket for each person on board. The only exceptions are sailboards and certain racing shells.
- In addition to the above requirements, vessels 16 feet in length or longer, except a canoe or kayak, must have one USCG–approved throwable device on board and readily accessible.
- All children 12 years of age and younger **must wear** a USCG–approved wearable life jacket while underway on any vessel. The life jacket must be fastened according to the manufacturer’s recommended use and must fit the child properly.
- If a person chooses to wear a life jacket that is not USCG approved (when not specifically required), a properly fitting USCG–approved life jacket must be carried on board the vessel to meet the state and federal carriage requirements.
- Each person on a PWC **must wear** a USCG–approved life jacket, and all closures of the life jacket must be fastened or secured according to the manufacturer’s design or recommended use and must be adjusted for a snug fit.
- Each person who is wakesurfing or being towed behind a vessel on water skis or a similar device must wear a life jacket.
- All life jackets must be in good and serviceable condition, must be readily accessible, and must be of the proper size for the intended wearer. Sizing for life jackets is based on body weight and chest size.

### Life Jacket Label

Every USCG–approved life jacket has a label that contains important information. While boating, you may encounter old- or new-style life jacket labels.

Not all life jackets available are USCG approved. Regardless if the life jacket label is in the old or new style, there must be a USCG approval number, and the life jacket must be used in accordance with the labeling information to meet the legal requirements.

- The older legacy labels have a type number (Types I to V).
  - The type number indicates the conditions and the intended use for which the life jacket is designed.
  - Life jackets with these labels may still be used in the country where they are approved as long as they are in serviceable condition.
- The new labels have a performance level icon that contains a number, typically ranging from 50 to 150.
  - A lower number means the life jacket is intended for near-shore activities in calm waters. Life jackets designed for near-shore use offer greater mobility and comfort. However, they will not turn most unconscious persons face up.
  - A higher number means the life jacket is intended for offshore activities. Life jackets designed for offshore use offer greater flotation, turning ability, and stability.
  - Life jackets with these labels are approved for use in both the U.S. and Canada.



## Warnings

Some life jackets are **not** approved for certain activities:



Water-skiing



PWC or  
wakeboarding



Tubing



Whitewater  
paddling

## Turn Ability



The life jacket will turn  
an unconscious person  
face up. Test before use.



The life jacket will not turn  
an unconscious person  
face up.

**Inflatable life jackets** must have a full cylinder, green status indicators, and an accessible and intact lanyard or lever. Inflatable life jackets are recommended only for strong swimmers and must be USCG approved. Wear an inherently buoyant life jacket and not inflatable life jackets for PWC, water-skiing, tubing, or whitewater boating activities.

## Navigation Lights

The required navigation lights must be displayed between sunset and sunrise and during periods of restricted visibility, such as fog or heavy rain. For requirements for larger vessels, see the USCG's *Navigation Rules*.

### Power-Driven Vessels When Underway

**If less than 65.6 feet (20 meters) long**, these vessels must exhibit the lights as shown in illustration 1. Remember, power-driven vessels include sailboats operating under engine power.


The required lights are:

- Red and green sidelights visible from a distance of at least two miles away—or if less than 39.4 feet (12 meters) long, at least one mile away—on a dark, clear night.
- An all-round white light or both a masthead light and a sternlight. These lights must be visible from a distance of at least two miles away on a dark, clear night. The all-round white light (or the masthead light) must be at least 3.3 feet (one meter) higher than the sidelights.

## 1. Power-Driven Vessels Less Than 65.6 Feet (20 Meters)



The masthead light and sternlight may be combined as an all-round white light on vessels less than 39.4 feet long.



## 2. Unpowered Vessels Less Than 65.6 Feet (20 Meters)



An alternative to the sidelights and sternlight is a combination red, green, and white light, which must be exhibited near the top of the mast.

## 3. Unpowered Vessels Less Than 23.0 Feet (7 Meters)



To prevent a collision, vessel operators should never leave shore without a flashlight. Even if you plan to return before dark, unforeseen developments might delay your return past nightfall.

## Unpowered Vessels When Underway

Unpowered vessels are sailboats or vessels that are paddled, poled, or rowed.

- **If less than 65.6 feet (20 meters) long**, these vessels must exhibit the lights as shown in illustration 2. The required lights are:
  - Red and green sidelights visible from at least two miles away—or if less than 39.4 feet (**12 meters**) long, at least one mile away.
  - A sternlight visible from at least two miles away.
- **If less than 23.0 feet (7 meters) long**, these vessels should:
  - If practical, exhibit the same lights as required for unpowered vessels less than 65.6 feet (**20 meters**) in length.
  - If not practical, have on hand at least one lantern or flashlight shining a white light as in illustration 3.

## All Vessels When Not Underway

**All vessels** are required to display a white light visible from all directions whenever they are moored or anchored outside a designated mooring area between sunset and sunrise.

## Fire Extinguishers

Any non-rechargeable (disposable) fire extinguisher that is older than 12 years should be removed from service. Refer to the date of manufacturing stamped on the bottle; for example, “05” means “2005.”

- Federal laws require all vessels, including PWC, to have a Type B fire extinguisher on board if one or more of the following conditions exist:
  - Any inboard engine
  - Closed compartments where portable fuel tanks may be stored
  - Double bottoms not sealed to the hull or which are not filled completely with flotation material
  - Closed living spaces
  - Closed storage compartments in which flammable or combustible materials may be stored
  - Permanently installed fuel tanks (any tank where the removal of the tank is hampered by the installation of tie-down straps or clamps)

- Approved types of fire extinguishers are identified by the following marking on the label—"Marine Type USCG Approved"—followed by the type and size symbols and the approval number.
- When required by the USCG, fire extinguishers must be on board the vessel and readily accessible—where they can be easily reached. When deciding on a place to store a fire extinguisher, make sure to consider how easy it is to reach in the event of a fire. It is recommended that the fire extinguisher be conspicuously and securely mounted on its intended hanger or bracket.

Vessels that have a **model year** of 2018 and newer may carry only 5-B or 20-B rated fire extinguishers with date stamp. Vessels with a model year between 1953 and 2017 may carry either:

- Unexpired 5-B or 20-B rated fire extinguishers *or...*
- B-I or B-II rated fire extinguishers that are in good and serviceable condition.

**Model Year** means the period beginning June 1 of a year and ending on July 31 of the following year and being designated by the year in which it ends.


Use this chart to determine the size and quantity required for your vessel.

<b>Length of Vessel</b>	<b>Without Fixed System</b>	<b>With Fixed System*</b>
Less than 26 ft.	one 5-B	none
26 ft. to less than 40 ft.	two 5-B ( <b>or</b> one 20-B)	one 5-B
40 ft. to less than 65 ft.	three 5-B ( <b>or</b> one 20-B and one 5-B)	two 5-B ( <b>or</b> one 20-B)
*refers to a permanently installed fire extinguisher system		

*Note: One 20-B portable fire extinguisher may be substituted for two 5-B portable fire extinguishers. For vessels with a model year between 1953 and 2017, one 20-B/B-II portable fire extinguisher may be substituted for two 5-B/B-I portable fire extinguishers.*

## Fire Extinguisher Charge Indicators

Check the charge level of your fire extinguishers regularly. Replace them immediately if they are not fully charged.



**green button**

To check this style of extinguisher, depress the green button. If it is fully charged, the green button should pop back out immediately.




On this style of fire extinguisher, the needle indicator should be in the "full" range.

- Extinguishers must not be expired or appear to have been previously used. They must be maintained in good and serviceable condition. Good and serviceable condition means that the fire extinguisher on board:
  - Is charged and indicates it is charged if the extinguisher has a pressure gauge reading or indicator *and...*
  - Has a pin lock that is firmly in place *and...*
  - Does not show visible signs of significant corrosion or damage *and...*
  - Has a discharge nozzle that is clean and free of obstructions.

## Ventilation Systems

The purpose of ventilation systems is to avoid explosions by removing flammable gases. Properly installed ventilation systems greatly reduce the chance of a life-threatening explosion.



- All gasoline-powered vessels constructed in a way that would entrap fumes must be properly and efficiently vented to remove the fumes. It is recommended that at least one intake duct extend from a point midway to the bilge or below the level of the carburetor air intake, and at least one exhaust duct extend from the open atmosphere to the lower bilge.
- If your vessel is equipped with a power ventilation system, turn it on for ***at least four minutes*** in either of these situations:
  - After fueling
  - Before starting the engine
- If your vessel is not equipped with a power ventilation system (for example, a PWC), open the engine compartment, and sniff for gasoline fumes before starting the engine.
- Regularly check the ventilation ducts for obstructions, such as birds' nests. Make sure you can feel air coming out of the cowl when the ventilation system is turned on.

## Backfire Flame Arrestors

Backfire flame arrestors are designed to prevent the ignition of gasoline vapors in case the engine backfires.

- All powerboats (except outboards) that are fueled with gasoline must have an approved backfire flame arrestor on each carburetor.
- Backfire flame arrestors must be:
  - In good and serviceable condition ***and...***
  - USCG approved (must comply with SAE J-1928 or UL 1111 standards).
- Periodically clean the flame arrestor(s) and check for damage. The elements must be clean, and the grids must be tight enough to prevent flames from passing through.
- Automotive-type air cleaners are not adequate for marine use and are not permitted.

## Mufflers and Noise Level Limits

Vessel operators may not hear sound signals or voices if the engine is not adequately muffled.

- All vessel engines must be equipped with an efficient muffler, underwater exhaust, or other effective muffling device that prevents excessive or unusual noise.
- A vessel operating on Arizona's public waters must not exceed any of the following noise levels:
  - A noise level of 86 dBA when the sound level is measured at 50 feet or more from the vessel
  - For an engine manufactured before January 1, 1993, a noise level of 90 dBA when the stationary sound level test (SAE J-2005) is performed
  - For an engine manufactured on or after January 1, 1993, a noise level of 88 dBA when the stationary sound level test (SAE J-2005) is performed
  - A noise level of 75 dBA when the shoreline sound level test (SAE J-1970) is performed

## Sound-Producing Devices

In periods of reduced visibility or whenever a vessel operator needs to signal his or her intentions or position, a sound-producing device is essential.

- Five or more short blasts mean danger or doubt, which is very important for all boaters to remember.
- Federal law requires that vessels operating on federally controlled waters, such as the Colorado River and Lake System, be equipped with sound-producing device(s). On federally controlled waters:
  - Vessels less than 39.4 feet (12 meters) in length, which includes PWC, must have some way of making an efficient sound signal. Examples are a handheld air horn, an athletic whistle, an installed horn, etc. A human voice is not acceptable.



- Vessels that are 39.4 feet (12 meters) or more in length must have a sound-producing device that can produce an efficient sound signal. The sound signal should be audible for one-half mile and should last for 4 to 6 seconds.

## Visual Distress Signals (VDSs)

Visual distress signals (VDSs) allow vessel operators to signal for help in the event of an emergency.

- Vessels on federally controlled waters must be equipped with VDSs that are USCG approved, in serviceable condition, and readily accessible.
- All vessels, regardless of length or type, are required to carry night signals when operating between sunset and sunrise. Most vessels must carry day signals also. Exceptions to the requirement for day signals are:
  - Recreational vessels that are less than 16 feet in length
  - Non-motorized open sailboats that are less than 26 feet in length
  - Manually propelled vessels
- If pyrotechnic VDSs are used, they must be dated. Expired VDSs may be carried on board, but a minimum of three unexpired VDSs must be carried in the vessel.
- The following combinations of signals are examples of VDSs that could be carried on board to satisfy USCG requirements:
  - Three handheld red flares (day and night)
  - One handheld red flare and two red meteors (day and night)
  - One handheld orange smoke signal (day), two floating orange smoke signals (day), and one electric light (night only)
- It is prohibited to display VDSs while on the water unless assistance is required to prevent immediate or potential danger to persons on board a vessel.

VDSs are classified as day signals (visible in bright sunlight), night signals (visible at night), or both day and night signals. VDSs are either pyrotechnic (smoke and flames) or non-pyrotechnic (non-combustible).



### Day

Handheld Orange Smoke (Pyrotechnic)  
Floating Orange Smoke (Pyrotechnic)  
Orange Flag (Non-Pyrotechnic)

### Night

Electric Light (Non-Pyrotechnic)

### Day and Night

Red Meteor (Pyrotechnic)  
Red Flare (Pyrotechnic)

### Federally Controlled Waters

Vessels must observe federal requirements on these waters:

- Coastal waters
- The Great Lakes
- Territorial seas
- Waters that are two miles wide or wider and are connected directly to one of the above
- Colorado River and Lake System



### Arm Signal

Although this signal does not meet VDS equipment requirements, wave your arms to summon help if you do not have other distress signals on board.

## On the Water

In addition to the laws mentioned previously, there are other Arizona regulations that apply on Arizona waterways.

### Unlawful and Dangerous Operation

Arizona law designates these dangerous operating practices as illegal.

- **Negligent or Reckless Operation** of a vessel is operating in a manner that causes danger to others or their property, such as:
  - Operating in a restricted area, such as a marked swimming area
  - Operating while passenger(s) are positioned in the bow such that the operator's view is obstructed
  - Weaving through congested waterway traffic
  - Chasing, harassing, or disturbing wildlife
  - Teak surfing or platform dragging
- **Speed Restrictions** require the operator to maintain a proper speed while operating a vessel. Specifically, it is illegal to:
  - Operate a vessel at speeds greater than are reasonable or proper given the existing waterway traffic, persons in the water, and weather conditions.
  - Exceed any posted speed limits.
  - Operate a vessel at greater than “**wakeless speed**” in a posted no wake zone.
  - Operate a vessel at speeds that may cause injury or damage to any other person, another vessel, or the property of others. This includes causing damage or danger from the wake of your vessel.
- **Riding on the Bow or Gunwales** is allowing passengers to ride where there may be a chance of falling overboard while underway at greater than “**no wake speed**” on a powerboat. Specifically, this means allowing passengers to ride on the covered bow, transom, swim step, or gunwales unless these are designed for carrying passengers at all speeds.

**“Wakeless Speed” or “No Wake Speed”** means a speed that does not create a wake and is never in excess of 5 miles per hour.

- **Overloading** is loading the vessel beyond its safe carrying capacity or the recommended capacity shown on the capacity plate. Take into consideration the weather and other operating conditions when determining if the vessel is overloaded.
- **Failure to Follow Navigational Rules** is operating a vessel in violation of the navigational rules of Arizona waters.
  - Specifically, operators of vessels:
    - Must follow the navigational rules shown in the section “Encountering Other Vessels.”
    - ***Must follow a counter-clockwise traffic flow.***
    - Leaving shore must give way to approaching vessels.
  - An exception to these rules is waterways where power-driven vessels are prohibited.
- **Auxiliary Lighting:** It is unlawful under federal and state laws to display any type of lights that can be mistaken for navigation lights or that obscure the visibility or interfere with the interpretation of any required navigation lights. Specifically, red, green, and white lights may only be displayed at night in configurations described in “Navigation Lights.” At no time may any blue lights be displayed because they are reserved exclusively for emergency or law enforcement vessels.



**Remember—it is your responsibility to know the law.**

On waterways shared with other states, such as the Colorado River, other states’ laws and federal regulations apply. Always know all applicable boating laws and regulations.

## Alcohol and Drugs

Arizona law prohibits anyone from operating a power-driven vessel while under the influence of alcohol or any drug that causes the person to be even slightly impaired. Alcohol and drugs cause impaired balance, blurred vision, poor coordination, impaired judgment, and slower reaction times. Alcohol is a major contributor to boating accidents and fatalities. The state of Arizona's operating under the influence (OUI) law mirrors the state's vehicular driving under the influence (DUI) laws and penalties. Here is the OUI law.

- A person is considered to be operating under the influence of alcohol if he or she has blood alcohol concentration (BAC) of 0.08% but less than 0.15% as determined by a test of his or her breath, blood, or urine. "Extreme OUI" is a BAC of 0.15% but less than 0.20%, and "Super Extreme OUI" is a BAC of 0.20% and higher.
  - If convicted of "OUI," a person can be fined up to \$1,450 and jailed for up to 10 days.
  - If convicted of "Extreme OUI," a person can be fined up to \$2,700 and jailed for up to 30 days.
  - If convicted of "Super Extreme OUI," a person can be fined up to \$3,150 and jailed for up to 45 days.
  - Subsequent convictions and persons convicted of "Aggravated OUI" are subject to even more severe penalties.
- By operating a vessel on Arizona waters, you have consented to be tested for alcohol or drugs if arrested by a law enforcement officer for alleged violations under Arizona *boating while intoxicated* law.

## Obstructing Navigation

It is illegal to:

- Anchor a vessel in a channel or launch area in a way that will prevent or interfere with any other vessel passing through the same area.

- Moor or attach a vessel to a buoy (other than a mooring buoy), beacon, light, or any other navigational aid placed on public waters by proper authorities.
- Move, displace, tamper with, damage, or destroy any navigational aid.
- Place buoys, markers, or navigational aids in the water without proper authorization.
- Obstruct a pier, boat ramp, or access to any facility.
- Interfere unreasonably or unnecessarily with other vessels' use of the waterways or areas used for launching into these waterways.
- Moor, anchor, or fasten to shore for more than 14 consecutive days any vessel on public waters (see the section "Mooring Buoy").

## Accidents and Casualties

- An operator involved in a boating accident must:
  - Stop his or her vessel *immediately* at the scene of the accident *and...*
  - Give assistance to anyone injured or minimize any danger caused by the accident unless doing so would seriously endanger his or her vessel or passengers *and...*
  - Give his or her name, address, and the identifying number of his or her vessel to anyone injured in the accident and to the owner of any damaged property.
- Vessel operators involved in an accident must send a boating accident report directly to: **Arizona Game and Fish Department, Attn: Boating Law Administrator, 5000 W. Carefree Highway, Phoenix, AZ 85086.**
  - The operator must report the accident in writing to the AZGFD within 48 hours if a person is injured or dies.
  - The operator must report the accident in writing to the AZGFD within five days if damage to the vessel and/or other property exceeds \$500.
- Boating accident report forms are available from law enforcement personnel at the lakes, first-aid stations, marinas, or ranger stations, or from the AZGFD.

## Diver-Down Flags

- Scuba divers and snorkelers must display a diver-down flag to mark their diving areas. The flag must be displayed whenever someone is diving below the surface.
- Vessels should stay as far away from a diver-down flag as is reasonable and prudent for the circumstances. The suggested safe distance from a flag is 100 yards.



**Divers Flag**



**Alfa Flag**

A rectangular red flag with a white diagonal stripe is used on Arizona waters, including the Colorado River and Lake System.

A blue-and-white International Code Flag A (or Alfa flag) is used on federally controlled waters.

## Discharge of Oil and Other Hazardous Substances

It is illegal to discharge oil or hazardous substances.


- You must dispose of oil waste in an approved oil waste container.
- Use bilge absorbents (bilge pillows) in the bilge area to absorb any oil or fuel, preventing it from being pumped back into the water. Secure the bilge pillow to avoid interference with the bilge pump and blower system.
- Refueling on the water or the shoreline is strongly discouraged because any spillage into the water or within 100 feet of the shoreline is a criminal violation. Petroleum spills can easily be seen on the surface of the water if a “rainbow sheen” can be observed while refueling.

If your vessel discharges oil or hazardous substances into the water:

- Call the National Response Center at **1-800-424-8802**.
- Also, report the discharge to the Arizona Department of Environmental Quality at **1-800-234-5677**.

## Discharge of Sewage and Waste

- State law prohibits the discharging of any sewage into the waters or onto the shorelines of Arizona. Use restroom facilities provided on the shore or floating restroom facilities. Consult a lake map for the locations of facilities.
- If you have a vessel with installed toilet facilities, it must have an operable marine sanitation device (MSD) on board. All installed devices must be USCG certified. Vessels 65 feet or less in length may use a Type I, II, or III MSD. Vessels over 65 feet must install a Type II or III MSD.



### Types of MSDs

A Type III MSD is the simplest and most common, consisting of a holding tank or portable toilet. Waste is to be discharged into a pump-out facility.

## Discharge of Trash

It is illegal to dump garbage, plastics, debris, or filthy or smelly objects or substances into any Arizona waters or shorelines. Many forms of litter can kill birds, fish, and other aquatic wildlife.

- You should store trash in a container while on board, and place it in a proper receptacle after returning to shore.
- If boating on federally controlled waters and your vessel is 26 feet or longer, you must display a Garbage Disposal Placard that is at least 4 x 9 inches and notifies passengers and crew about discharge restrictions.

## Specifically for PWC

Personal watercraft (PWC) operators must obey additional legal requirements that apply specifically to the operation of PWC on Arizona waters. The definition of a “personal watercraft” is a watercraft that is less than 16 feet long, is propelled by machinery powering a water jet pump, and is designed to be operated by a person who sits, stands, or kneels on, rather than sitting or standing inside, the watercraft.

### Requirements Specific to PWC

- Each person on board a PWC ***must wear*** USCG–approved wearable life jackets. They must be worn according to the manufacturer’s design and recommended use. All closures must be fastened and adjusted for a snug fit.
- An operator of a PWC equipped with a lanyard-type engine cut-off switch (ECOS) must attach the lanyard to his or her person, clothing, or life jacket.
- It is illegal to operate a PWC between sunset and sunrise or during periods of restricted visibility unless the PWC is equipped with the proper navigation lights.
- PWC must be operated in a careful and responsible manner. It is considered reckless operation if a PWC operator commits *two or more* of the following acts simultaneously:
  - Operating within 60 feet of another vessel above a wakeless speed.
  - Operating within the vicinity of a vessel in a manner that obstructs the visibility of either operator.
  - Heading into the wake of a vessel that is within 60 feet and causing half or more of the length of the PWC to leave the water.
  - Operating within 60 feet of another vessel, maneuvering quickly, turning sharply, or swerving unless the maneuver is necessary to avoid a collision.
- A PWC may not be loaded with passengers and gear beyond the safe carrying capacity recommended by the PWC manufacturer.

## Sharing Your PWC...Safely

Sharing the fun of your PWC with friends is all part of the boating experience. Before you share your PWC, however, make sure that others you allow to operate it understand their responsibilities as an operator. They need to know that they have the same responsibilities as any other vessel operator, including obeying the navigation rules.

In addition:

- Make sure that anyone you allow to operate your PWC meets the minimum age (12 years of age and older) and education requirements for PWC operation in Arizona and the local waterway you are using.
- Show new operators how to start and reboard the PWC while on shore or in shallow water.
- Explain how to steer and control the PWC. Tell all new operators, and remind experienced operators, that ***power is required for steering control.***
- Make sure that the operator understands how to use the ECOS and attaches the lanyard to his or her person or life jacket before starting the engine.
- Have anyone new to PWC go out in an uncongested area first. Tell them to stay clear of other PWC, boats, or persons in the water.
- Explain how to recognize a “slow, no wake speed” marker and what to do when approaching one.




# Surface Watersports

Vessel operators towing a person(s) on water skis or a similar device have additional laws.

## Towed Sports

- If a vessel is towing a person(s) on water skis or any another similar device or is involved in wakesurfing, at least two persons must be on board—one to operate the vessel and a second person to observe the towed person(s). The observer must be at least 12 years old and be physically capable and mentally competent to act as an observer of a water-skier or wakesurfer.
- Every person who is wakesurfing or being towed behind a vessel on water skis or a similar device must wear a life jacket. The AZGFD recommends the use of a USCG–approved, brightly colored, wearable flotation aid. The brightly colored life jacket aids in making a skier more visible to other vessels.
- Water-skiing is restricted to daylight hours only. It is illegal to tow a person(s) on water skis, surfboard, or other similar device from sunset to sunrise.
- Both the operator of the towing vessel and the skier must operate in a safe manner. A reasonable distance from other vessels, people, and property must be maintained so as not to cause danger to the life or property of others.
- State law makes the person being towed (the skier) responsible if he or she behaves in a careless, reckless, or negligent manner.
- **“Wake Responsibly”:** Always try to wakeboard and wakesurf toward the center of any given body of water and avoid narrow channels and smaller bays. Slow down activity as boats pass, and stay at least 150 feet from other boaters and shorelines. Respect others and avoid multiple passes and turns in the same area.




- Vessels towing person(s) on water skis or a similar device must carry and use a bright red or orange skier-down flag that is at least 12 x 12 inches in size and mounted on a handle. The observer must continuously observe the skier(s) and display a skier-down flag whenever a skier is in the water after falling or while preparing to ski.
- If towing a skier with a PWC, the same water-skiing laws apply. **Do not exceed the carrying capacity of the PWC.**




## Hand Signals for Skiers

Knowing proper hand signals will help the skier(s) communicate with their boat operator or the observer.



**Skier OK**




**Stop**



**Skier down—watch!**



**Speed up**



**Slow down**



**Speed OK**



**Turn left**



**Turn right**

## Avoiding Propeller Strike Injuries

Most propeller strike accidents result from operator error. Victims include swimmers, scuba divers, fallen water-skiers, and boat operators or passengers. Most propeller accidents can be prevented by following basic safe boating practices.

- Maintain a proper lookout. The primary cause of propeller strike accidents is operator inattention.
- Make sure the engine is off so that the propeller is not rotating when passengers are boarding or leaving a boat.
- Never start a boat with the engine in gear.
- Slow down when approaching congested areas and anchorages. In congested areas, always be alert for swimmers and divers.
- Learn to recognize warning buoys that mark swimming and hazardous areas.
- Keep the boat away from marked swimming and diving areas. Become familiar with the red-and-white or blue-and-white diver-down flags signaling that divers are below the surface.
- Make sure that passengers are seated properly before getting underway. Some operators of larger boats with several passengers have caused injuries by putting the engine in gear while people were still swimming or diving from the boat.
- Never ride on a seat back, gunwale, transom, or bow.

### Devices That Reduce Propeller Strikes

There are several new technologies designed to reduce propeller strikes. The effectiveness of the devices varies, depending on the boat and the operating environment. For more information, visit the USCG boating safety website at [www.uscgboating.org/recreational-boaters/](http://www.uscgboating.org/recreational-boaters/).

### Remember...

Operators of recreational vessels less than 26 feet in length are required to use the engine cut-off switch (ECOS) if the vessel is equipped with such a device. Operators must use the ECOS whenever the vessel is operating on plane or above displacement speed.

Be sure to check with the state boating agency where you are boating to determine how this new USCG rule applies locally. For more information on this requirement, visit

[www.uscgboating.org/recreational-boaters/engine-cut-off-switch-faq.php](http://www.uscgboating.org/recreational-boaters/engine-cut-off-switch-faq.php).

## Remember to “Pull the Plug” on mussels. Always “Clean, Drain, & Dry” your watercraft and equipment.

The following are mandatory protocols for all watercraft/equipment leaving Aquatic Invasive Species (AIS) listed waters/locations (A.R.S. 17.255–Director’s Orders 3).

**DAY USE:** For watercraft/equipment that have been on listed waters for **five or less** consecutive days.

- Step 1. **Clean:** Before leaving the boat ramp, remove all organic material (mud, plants, animals).
- Step 2. **Drain:** Pull the plug, and remove all standing water from your vessel (bilge, live well, etc.).
- Step 3. **Dry:** Completely dry the vessel and all equipment before launching in another water.

\*If the boat cannot be dried completely before launching in another water (i.e., ballast tanks, inboard/outboard engines, etc.), call the AIS program at **623-236-7608** to schedule a free inspection.

**LONG-TERM USE:** For watercraft/equipment that have been on listed waters **six or more** consecutive days.

- Step 1. At least 72 hours before transporting away from the infected waterbody, schedule an inspection and possible decontamination by calling our AIS program at **623-236-7608** or by visiting our website at **[www.azgfd.com/fishing-2/aquatic-invasive-species](http://www.azgfd.com/fishing-2/aquatic-invasive-species)** (and click on “Request a free watercraft inspection and decontamination”).

- Step 2. **Clean, Drain, & Dry** the boat/equipment as described in the Day Use section.

- Step 3. Meet the appropriate dry times: seven consecutive days during the months of May through October and 18 consecutive days during the months of November through April.

**Remember:** that it is **illegal** to transport Aquatic Invasive Species within the state of Arizona (A.R.S 17-255.02(1)). When traveling across state lines, please visit **[www.westernais.org/watercraft](http://www.westernais.org/watercraft)** for applicable AIS laws and state contacts.



## Vessel and Engine Restrictions

### Powerboats are restricted to a single electric motor on:

Ackre Lake	Granite Basin Lake	Santa Fe Lake
Bear Canyon Lake	Horsethief Basin Lake	Scott's Reservoir
Bunch Reservoir	Hulsey Lake	Sierra Blanca Lake
Carnero Lake	J.D. Dam Lake	Soldier Lake
Chaparral Park Lake	Knoll Lake	(in Coconino Co.)
Cluff Ponds	Lee Valley Lake	Stehr Lake
Coconino Reservoir	McKellips Pond	Stoneman Lake
Coors Lake	Pratt Lake	Tunnel Reservoir
Dankworth Pond	Quigley Lake	Whitehorse Lake
Dogtown Reservoir	Redondo Lake	Willow Valley Lake
Fortuna Lake	Riggs Flat Lake	Woodland Reservoir
Goldwater Lake	Roper Lake	Woods Canyon Lake

### Powerboats are restricted to using only a single electric motor or a single gasoline engine of 10 horsepower or less on:

Arivaca Lake	Crescent Lake	Nelson Reservoir
Ashurst Lake	Fool Hollow Lake	Parker Canyon Lake
Becker Lake	Kaibab Lake	Peña Blanca Lake
Big Lake	Kinnikinick Lake	Rainbow Lake
Black Canyon Lake	Little Mormon Lake	River Reservoir
Blue Ridge Reservoir	Lower Lake Mary	Show Low Lake
Cataract Lake	Luna Lake	Whipple Lake
Chevelon Canyon Lake	Lynx Lake	White Mountain Lake
Cholla Lake Hot Pond	Marshall Lake	(in Apache Co.)
Concho Lake	Mexican Hay Lake	Willow Springs Lake

## Other Restrictions

- Vessels are prohibited on Frye Mesa Reservoir, Rose Canyon Lake, and Snow Flat Lake.
- Vessels are prohibited from entering the following waters during these dates\*:
  - The posted portion of Luna Lake from February 15 through July 31
  - The posted portions of Roosevelt Lake from November 15 through February 15
  - The posted portion of Mittry Lake from November 15 through February 15
  - The posted portion of the Agua Fria Arm of Lake Pleasant from December 15 to June 15
  - The posted portions of Woods Canyon Lake, Show Low Lake, Lynx Lake, Alamo Lake, and Roosevelt Lake corresponding to eagle nest closure areas

\*Closure dates may vary. Always check the dates posted on closure buoys.

# Arizona Boater's Directory



**Arizona Game and Fish Department**  
**5000 W. Carefree Hwy.**  
**Phoenix, AZ 85086**  
**602-942-3000**

## Arizona Game and Fish Department Regional Offices

**Flagstaff**  
 3500 S. Lake Mary Rd.  
 Flagstaff, AZ 86001  
 928-774-5045

**Kingman**  
 5325 N. Stockton Hill Rd.  
 Kingman, AZ 86409  
 928-692-7700

**Mesa**  
 7200 E. University Ave.  
 Mesa, AZ 85207  
 480-981-9400

**Pinetop**  
 2878 E. White Mountain Blvd.  
 Pinetop, AZ 85935  
 928-367-4281

**Tucson**  
 555 N. Greasewood Rd.  
 Tucson, AZ 85745  
 520-628-5376

**Yuma**  
 9140 E. 28th St.  
 Yuma, AZ 85365  
 928-342-0091

## Arizona Game and Fish Department Other Important Telephone Numbers

**Phoenix Headquarters** . . . . 602-942-3000  
**Aquatic Invasive Species** . . 623-236-7271  
**Boating Education** . . . . . 623-236-7258  
**Off-Highway Vehicle**  
**Information** . . . . . 623-236-7237

**Operation Game Thief—report**  
**wildlife violations** . . . 1-800-352-0700  
**Watercraft** . . . . . 602-942-3000

For additional info, visit [www.azgfd.gov](http://www.azgfd.gov).

## State Parks

Alamo Lake State Park . . . 928-669-2088  
 Buckskin Mountain State Park  
 (Colorado River) . . . . . 928-667-3231  
 Cattail Cove State Park  
 (Lake Havasu) . . . . . 928-855-1223  
 Fool Hollow Lake  
 Recreation Area . . . . . 928-537-3680

Lake Havasu State Park  
 (Windsor Beach) . . . . . 928-855-2784  
 Lyman Lake State Park . . . 928-337-4441  
 Patagonia Lake  
 State Park . . . . . 520-287-6965  
 River Island State Park  
 (Colorado River) . . . . . 928-667-3386  
 Roper Lake State Park . . . 928-428-6760

## County Sheriff Offices

Apache County . . . . . 928-337-4321  
 Cochise County . . . . . 520-432-9500  
 Coconino County . . . . . 928-774-4523  
 Graham County . . . . . 928-428-3141  
 Greenlee County . . . . . 928-865-4149  
 La Paz County . . . . . 928-669-6141  
 Maricopa County . . . . . 602-876-1000

Mohave County . . . . . 928-753-9141  
 Navajo County . . . . . 928-524-4000  
 Pima County . . . . . 520-351-4600  
 Pinal County . . . . . 520-866-5111  
 Santa Cruz County . . . . . 520-375-7800  
 Yavapai County . . . . . 928-771-3260  
 Yuma County . . . . . 928-783-4427

Take a  
**Boating Education Class**  
[www.azgfd.gov/boating](http://www.azgfd.gov/boating)  
**623-236-7258**

## Arizona Required Equipment Checklist



	Paddlecraft	PWC	Boat Less Than 16 Ft.	Boat 16 Ft. or Longer
<b>Certificate of Number on Board</b>		✓	✓	✓
<b>Registration Decals Displayed</b>		✓	✓	✓
<b>Wearable Life Jackets</b>	✓ <sup>2</sup>	✓ <sup>1</sup>	✓ <sup>2</sup>	✓ <sup>2</sup>
<b>Throwable Devices</b>				✓
<b>Type 5-B Fire Extinguisher</b>		✓	✓	✓
<b>Backfire Flame Arrestor</b>		✓	✓ <sup>3</sup>	✓ <sup>3</sup>
<b>Ventilation System</b>		✓	✓	✓
<b>Muffler</b>		✓	✓	✓
<b>Horn, Whistle, or Bell</b>	✓ <sup>4</sup>	✓ <sup>4</sup>	✓ <sup>4</sup>	✓ <sup>4</sup>
<b>Daytime VDSs</b>				✓ <sup>4</sup>
<b>Nighttime VDSs</b>		✓ <sup>4</sup>	✓ <sup>4</sup>	✓ <sup>4</sup>
<b>Navigation Lights</b>	✓	✓ <sup>5</sup>	✓	✓

1. Those on PWC *must wear* a wearable life jacket at all times.
2. Those 12 years of age and younger *must wear* a wearable life jacket while underway on any vessel.
3. Required on inboard engines.
4. Required when boating on federally controlled waters.
5. If a PWC is operated at night, it must be equipped with the required navigation lights.

*\*On boats longer than 26 feet, additional equipment is required.*



# ARIZONA GAME AND FISH

## SAVE TIME RENEW ONLINE

**ONLINE SERVICES AVAILABLE 24/7**



**IT'S AS EASY AS 1-2-3**


- 1. Go to [watercraft.azgfd.com](http://watercraft.azgfd.com).**
- 2. Select Start.**
- 3. Know your AZ Boat Number.**

---

**SIMPLIFY YOUR LIFE SAVE OUR EARTH GO PAPERLESS**  
RENEWING ONLINE WILL BE A VALUABLE CONTRIBUTION IN THE  
RESOLUTION OF OUR POLLUTION PROBLEMS TODAY.

---





## Boat Safe Boat Smart Boat Sober

### Take a Boating Class!

For more information,  
visit our website at  
[www.azgfd.gov/boating](http://www.azgfd.gov/boating).

#### Four principles of safe boating:

1. Wearing life jackets saves lives.
2. Boater education saves lives.
3. Safe boating saves lives.
4. Sober boating saves lives.

